

Full reproducible codes

1) Create directory 'data', 'src', 'results' in a CA2 folder

```
(base) weiqi@LSLab5-22:~$ cd Desktop
(base) weiqi@LSLab5-22:~/Desktop$ cd CA2
(base) weiqi@LSLab5-22:~/Desktop/CA2$ mkdir data src results
```

2) Download relevant packages

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install curl
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install fastqc
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install trimmomatic
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install picard-tools
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install bowtie bowtie2
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install samtools
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install libbz2-dev
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install zlib1g-dev
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install libncurses5-dev
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install libncursesw5-dev
(base) weiqi@LSLab5-22:~/Desktop/CA2$ sudo apt-get install liblzma-dev
(base) weiqi@LSLab5-22:~/Desktop/CA2$ wget
https://github.com/samtools/samtools/releases/download/1.9/(base) weiqi@LSLab5-
22:~/Desktop/CA2$ samtools-1.9.tar.bz2
(base) weiqi@LSLab5-22:~/Desktop/CA2$ tar -xjf samtools-1.9.tar.bz2
(base) weiqi@LSLab5-22:~/Desktop/CA2$ cd samtools-1.9
(base) weiqi@LSLab5-22:~/Desktop/CA2/samtools-1.9$ make
(base) weiqi@LSLab5-22:~/Desktop/CA2/samtools-1.9$ sudo make install
(base) weiqi@LSLab5-22:~/Desktop/CA2/samtools-1.9$ sudo apt-get install bedtools
```

3) Download mutated yeast clone (A0158131M.tgz) from nBox and put it in data folder

4) Prepare data by extracting out all the files from the "tarball"

```
(base) weiqi@LSLab5-22:~/Desktop/CA2/samtools-1.9$ cd ../data
(base) weiqi@LSLab5-22:~/Desktop/CA2/data$ tar -zxvf A0158131M.tgz
```

5) Quality control - Assessing quality using FastQC

```
(base) weiqi@LSLab5-22:~/Desktop/CA2/data$ cd ../results
(base) weiqi@LSLab5-22:~/Desktop/CA2/results$ mkdir fastqc
(base) weiqi@LSLab5-22:~/Desktop/CA2/results$ cd ../
(base) weiqi@LSLab5-22:~/Desktop/CA2$ fastqc data/*.fq -o results/fastqc
(base) weiqi@LSLab5-22:~/Desktop/CA2$ cd results/fastqc
(base) weiqi@LSLab5-22:~/Desktop/CA2/results/fastqc$ for filename in *.zip; do unzip $filename;
done
(base) weiqi@LSLab5-22:~/Desktop/CA2/results/fastqc$ cd ../..
(base) weiqi@LSLab5-22:~/Desktop/CA2$ mkdir -p docs
(base) weiqi@LSLab5-22:~/Desktop/CA2$ cat results/fastqc/*/summary.txt >
docs/fastq_summaries.txt
```

6) Check for any failed category: No failed results

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ grep FAIL docs/fastq_summaries.txt
```

7) Assess HTML files and decided not to trim as all categories passed.

8) Align reads to reference genome - prepare by downloading yeast genome (sacCer.fa) and transposon (ty5_6p.fa) from IVLE, and put it in data folder

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ mkdir combined
(base) weiqi@LSLab5-22:~/Desktop/CA2$ mkdir -p results/sam results/bam
(base) weiqi@LSLab5-22:~/Desktop/CA2$ bowtie2-build 'data/sacCer3.fa,data/ty5_6p.fa'
combine.indexing
```

9) Put combine.indexing files into a new folder called "combined"

10) Next, prepare 3 bash(.sh) scripts and put them in "src" folder. The scripts can be found in the github repository too.

11) Align paired-ends to reference genome

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ bash src/run-bowtie2.sh
```

12) Convert SAM file format to BAM file format

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ bash src/convert-to-bam.sh
```

13) Sort BAM file by coordinates

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ bash src/sort-bam-files.sh
```

14) Learn more about the BAM file

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ samtools flagstat results/bam/data-sorted.bam
```

15) Using SAM flags to filter to get improperly paired, and read and mates mapped

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ samtools view -h -f 1 -F 14 results/bam/data-sorted.bam | grep -e 'TY5' -e '^@' > data-sorted.sam
```

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ head data-sorted.sam
```

16) Make it into a .txt file so as to open on excel sheet to further filter and narrow down the regions to find the paired-ends and insertions on IGV later on

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ samtools view -h -f 1 -F 14 results/bam/data-sorted.bam | grep -e 'TY5' -e '^@' > data-sorted.txt
```

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ samtools view -S -b data-sorted.sam > data-sorted.bam
```

17) Index BAM files to allow visualisation of alignment on IGV

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ samtools index results/bam/data-sorted.bam
```

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ samtools index data-sorted.bam
```

18) Check the number of reads; 150

```
(base) weiqi@LSLab5-22:~/Desktop/CA2$ samtools view data-sorted.bam | wc -l
```